

# TOSHIBA

## OWNER'S MANUAL

### Projection Television

COLORSTREAM®



Introduction

Connecting  
your TV

Using the  
Remote Control

Setting up  
your TV

Using the TV's  
Features

Appendix

#### Owner's Record

The model number and serial number are on the back of your TV. Record these numbers in the spaces below. Refer to these numbers whenever you communicate with your Toshiba dealer about this TV.

Model number:

**53AX62**


Serial number:

# 53AX62






- 23) Always operate this equipment from a 120 VAC, 60 Hz power source only.



- 24) Always make sure the antenna system is properly grounded to provide adequate protection against voltage surges and built-up static charges (see Section 810 of the National Electric Code).




- 25) **! DANGER: RISK OF SERIOUS PERSONAL INJURY OR DEATH!**
- Use extreme care to make sure you are never in a position where your body (or any item you are in contact with, such as a ladder or screwdriver) can accidentally touch overhead power lines. Never locate the antenna near overhead power lines or other electrical circuits.
  - Never attempt to install any of the following during lightning activity:
    - a) an antenna system; or b) cables, wires, or any home theater component connected to an antenna or phone system.

## Care

For better performance and safer operation of your TOSHIBA TV, follow these recommendations and precautions:

- 26) Always sit approximately 10–25 feet away from the TV and as directly in front of it as possible. The picture can appear dull if you sit too far to the left or right of the TV, or if sunlight or room lights reflect on the screen. Turn the TV off to check for reflections on the screen, and then remove the source of reflections while viewing the TV.

- 27) Always unplug the TV before cleaning. Never use liquid or aerosol cleaners.




- 28) **! WARNING: RISK OF ELECTRIC SHOCK!** Never spill liquids or push objects of any kind into the TV cabinet slots.

- 29) [This item applies to projection TVs only.] If the air temperature rises suddenly (for example, when the TV is first delivered), condensation may form on the lenses. This can make the picture appear distorted or the color appear faded. If this happens, turn off the TV for 6 to 7 hours to allow the condensation to evaporate.

- 30) For added protection of your TV from lightning and power surges, always unplug the power cord and disconnect the antenna from the TV if you leave the TV unattended or unused for long periods of time.

- 31) During normal use, the TV may make occasional snapping or popping sounds. This is normal, especially when the unit is being turned on or off. If these sounds become frequent or continuous, unplug the power cord and contact a Toshiba Authorized Service Center.




- 32) **Possible Adverse Effects on TV Picture Tube:** If a fixed (non-moving) pattern remains on the TV screen for long periods of time, the image can become permanently engrained in the picture tube and cause subtle but permanent ghost images. **This type of damage is NOT COVERED BY YOUR WARRANTY.** Never leave your TV on for long periods of time while it is displaying the following formats or images:

- **Fixed Images**, such as PIP/POP windows, stock tickers, video game patterns, TV station logos, and websites.
- **Special Formats** that do not use the entire screen. For example, viewing letterbox style (16:9) media on a normal (4:3) display (gray bars at top and bottom of screen); or viewing normal style (4:3) media on a widescreen (16:9) display (gray bars on left and right sides of screen).


## Service

- 33) **! WARNING: RISK OF ELECTRIC SHOCK!** Never attempt to service the TV yourself. Opening and removing the covers may expose you to dangerous voltage or other hazards. Refer all servicing to a Toshiba Authorized Service Center.



- 34) If you have the TV serviced:

- Ask the service technician to use only replacement parts specified by the manufacturer.
- Upon completion of service, ask the service technician to perform routine safety checks to determine that the TV is in safe operating condition.



- 35) When the TV reaches the end of its useful life, ask a qualified service technician to properly dispose of the TV. Improper disposal may result in a picture tube implosion and possible personal injury.



<b>Important Safety Information .....</b>	<b>2-4</b>	
<b>Introduction .....</b>	<b>6</b>	
Welcome to Toshiba .....	6	
Exploring your new TV .....	6	
<b>Connecting your TV .....</b>	<b>7</b>	
Note regarding picture quality .....	7	
Connecting a VCR .....	7	
Connecting a cable converter box .....	8	
Connecting a cable converter box and a VCR .....	8	
Connecting a DVD player/satellite receiver and a VCR ...	9	
Connecting a DVD player with ColorStream® (component video) and a VCR .....	10	
Connecting two VCRs .....	10	
Connecting a camcorder .....	11	
Connecting an audio system .....	11	
Connecting an A/V receiver .....	12	
<b>Using the remote control .....</b>	<b>13</b>	
Preparing the remote control for use .....	13	
Installing the remote control batteries .....	13	
Remote control functional key chart .....	14	
Programming the remote control for use with your audio/video devices .....	16	
Device code setup .....	16	
Searching and sampling the code of a device (991) .....	16	
Verifying the device code (990) .....	17	
Using the Volume Lock feature (993) .....	17	
Operational feature reset (980) .....	17	
Device code table .....	18	
Learning about the remote control .....	22	
<b>Setting up your TV .....</b>	<b>23</b>	
Learning about the menu system .....	23	
Changing the on-screen display language .....	24	
Selecting the antenna input .....	24	
Adding channels to the TV's memory .....	25	
Programming channels automatically .....	25	
Adding and erasing channels manually .....	26	
Changing channels .....	26	
Adjusting the color convergence .....	27	
<b>Using the TV's features .....</b>	<b>28</b>	
Adjusting the channel settings .....	28	
Switching between two channels .....	28	
Programming your favorite channels .....	28	
Labeling channels .....	29	
Watching picture-in-picture (PIP) .....	31	
Switching the main and PIP pictures .....	32	
Changing the position of the PIP window .....	32	
Freezing the PIP picture .....	32	
Using the multi-window feature .....	32	
Using the multi-window channel preview function .....	33	
Using the multi-window favorite channel scan function .....	33	
Using the multi-window strobe function .....	33	
Using the LOCKS menu .....	34	
If you cannot remember your PIN code .....	34	
Entering the PIN code .....	34	
Using the V-CHIP menu .....	35	
ENABLE BLOCKING .....	35	
TV RATING (Independent rating system for broadcasters) .....	35	
MPAA RATING (Independent rating system for movies) .....	36	
BLOCKING OPTION .....	36	
Unlocking programs temporarily .....	37	
Locking channels .....	37	
Locking the video inputs .....	38	
Locking the front panel buttons .....	38	
Changing the PIN code .....	38	
Adjusting the picture .....	39	
Selecting the picture mode .....	39	
Adjusting the picture quality .....	39	
Saving your new picture preferences .....	40	
Using the flesh tone feature .....	40	
Using the noise reduction feature .....	40	
Selecting the color temperature .....	41	
Resetting your picture adjustments .....	41	
Watching video input .....	42	
Selecting the video source labels .....	42	
Using the closed caption feature .....	43	
Setting the sleep timer .....	44	
Setting the clock .....	44	
Adjusting the sound .....	45	
Muting the sound .....	45	
Selecting stereo/SAP broadcasts .....	45	
Using the surround sound feature .....	46	
Adjusting the sound quality .....	47	
Resetting your audio adjustments .....	47	
Using the sub-bass system (SBS) .....	48	
Turning off the built-in speakers .....	48	
Selecting the Audio OUT sound .....	49	
Using the StableSound® feature .....	49	
Selecting the background of the menu display .....	50	
Displaying on-screen information .....	50	
Viewing the demonstration mode .....	50	
Understanding the auto power off feature .....	51	
Understanding the last mode memory feature .....	51	
<b>Appendix .....</b>	<b>52</b>	
Specifications .....	52	
Troubleshooting .....	53	
Limited United States Warranty .....	54	
Limited Canada Warranty .....	55	

## Introduction

### Welcome to Toshiba

Congratulations! You have purchased one of the finest projection TVs on the market. The goal of this manual is to guide you through setting up and operating your Toshiba TV as quickly as possible.




This manual applies to model 53AX62.

Instructions in this manual are based on using the remote control. You can also use the buttons on the TV front panel if they have the same name as those on the remote control.

Please read all the safety and operating instructions carefully, and keep the manual for future reference.

### Exploring your new TV

You can operate the TV using the buttons on the front panel or remote control. The back panel and front panel (behind the door) provide all the terminal connections you will need to connect other equipment to the TV (see "Connecting your TV" on page 7).



## Connecting your TV


**Note:** Cables are not supplied with your TV.

- **Coaxial cable** is the cable that comes in from your antenna, cable TV service, or cable converter box. Coaxial cable uses "F" connectors.
- **Standard stereo A/V cables** usually come in sets of three, and are typically color-coded according to use: yellow for video, red for stereo right audio, and white for stereo left (or mono) audio. Your TV's standard A/V inputs are color-coded in the same manner as the cables.
- **S-Video cable** is for use with video equipment that has S-Video connectors.
- **Component video cables** come in sets of three (typically color-coded red, green, and blue), and are for use with video equipment that has component video connectors. Your TV's ColorStream® (component video) inputs are color-coded in the same manner as the cables.

### NOTE REGARDING PICTURE QUALITY

When connecting video equipment to your Toshiba TV:

- **For GOOD picture quality:** Use a standard yellow video cable.
- **For BETTER picture quality:** If your equipment has S-video connectors, use an S-video cable *instead of* a standard yellow video cable. (You still must connect the standard red and white audio cables for full system connection, but *do not connect a standard yellow video cable at the same time* or the picture performance will be unacceptable.)
- **For BEST picture quality:** If your equipment has component video connectors, use component video cables *instead of* a standard yellow video cable or S-video cable. (You still must connect the standard red and white audio cables for full system connection.)




**CAUTION:** Do not plug in any power cords until you have finished connecting all equipment.

## Connecting a VCR

This connection allows you to watch local channels and video programs, play or record on the VCR while watching TV, and record from one channel while watching another channel.

You will need:

- two coaxial cables
- one set of standard A/V cables



### Caution:

If you have a mono VCR, connect L/Mono to VCR Audio OUT using only one audio cable.

If you have an S-VHS VCR, use the S-video cable, instead of a standard video cable.

Do not connect a standard video cable and an S-video cable to Video-1 (or Video-2) at the same time, or the picture performance will be unacceptable.


The unauthorized recording, use, distribution, or revision of television programs, videotapes, DVDs, and other materials is prohibited under the Copyright Laws of the United States and other countries, and may subject you to civil and criminal liability.

## Connecting a cable converter box

This connection allows you to watch cable and premium channels. To use the TV's features, select ANT-1. To view premium channels, select ANT-2 and tune the TV to channel 3 or 4 (whichever is vacant in your area), and then use the converter box to change channels.

You will need:

- three coaxial cables



### Note:


When you use a converter box with your TV, the remote control will not operate some features, such as programming your favorite channels, labeling channels, and locking channels.

## Connecting a cable converter box and a VCR

This connection allows you to watch and record basic and premium cable channels, and watch videotapes. To use the TV's features, select ANT-1. To view premium channels or record with the VCR, select ANT-2 and tune the TV to channel 3 or 4 (whichever is vacant in your area), and then use the converter box to change channels.

You will need:

- one cable splitter
- four coaxial cables
- one set of standard A/V cables



### Note:

If you have a mono VCR, connect L/Mono to VCR Audio OUT using only one audio cable.

If you have an S-VHS VCR, use an S-video cable instead of a standard video cable. Do not connect a standard video cable and an S-video cable to Video-1 (or Video-2) at the same time or the picture performance will be unacceptable.

When you use a converter box with your TV, the remote control will not operate some features, such as programming your favorite channels, labeling channels, and locking channels.

The unauthorized recording, use, distribution, or revision of television programs, videotapes, DVDs, and other materials is prohibited under the Copyright Laws of the United States and other countries, and may subject you to civil and criminal liability.




## Connecting a DVD player/satellite receiver and a VCR

This connection allows you to watch DVD/satellite, VCR, and TV programs, and record one channel while watching another channel.

You will need:

- two (or three, if satellite receiver is used) coaxial cables
- one set of standard A/V cables
- one S-video cable
- one pair of standard audio cables



### Note:

For the highest possible picture quality from a DVD player/satellite receiver without component video, use an S-video cable between the TV and DVD player/satellite receiver. (If your DVD player or satellite receiver has component video, see page 12.)

Do not connect an S-video cable and a standard video cable to Video-1 (or Video-2) at the same time, or the picture performance will be unacceptable.

Do not connect the DVD player/satellite receiver and VCR to the same video channel on the TV. (See the illustration, which shows the DVD player/satellite receiver connected to Video-1 on the TV and the VCR connected to Video-2 on the TV.)

The unauthorized recording, use, distribution, or revision of television programs, videotapes, DVDs, and other materials is prohibited under the Copyright Laws of the United States and other countries, and may subject you to civil and criminal liability.

## Connecting a DVD player with ColorStream® (component video) and a VCR

This connection allows you to watch DVD, VCR, or TV programs, and record TV programs.


Your TV has ColorStream® (component video) connections. Connecting your TV to a DVD player with component video (such as a Toshiba DVD player with ColorStream®) can greatly enhance picture quality and performance.

You will need:

- two coaxial cables
- three pairs of audio cables (one single and two pairs of audio cables for a mono VCR)
- two video cables
- one set of component video cables
- one pair of standard audio cables

### Note:

To play a DVD, the DVD player and TV must use ColorStream (component video) connections, and the TV must be set to ColorStream mode (see page 42). To record from the DVD player, the VCR must select Line IN.



DVD player with ColorStream® (component video)

## Connecting two VCRs

This connection allows you to record (dub/edit) from one VCR to another VCR while watching a video program. You will also be able to record from one TV channel while watching another channel.

You will need:


- two coaxial cables
- one set of standard A/V cables

### Note:

Do not connect the same VCR to the output and input jacks on the TV at the same time.

If you are using an S-VHS VCR, use an S-video cable instead of a standard video cable for better picture performance. Do not connect a standard video cable and an S-video cable to Video-1 (or Video-2) at the same time, or the picture performance will be unacceptable.

To dub or edit, VCR 2 must select Line IN, and the TV must select Video-1.



The unauthorized recording, use, distribution, or revision of television programs, videotapes, DVDs, and other materials is prohibited under the Copyright Laws of the United States and other countries, and may subject you to civil and criminal liability.

\* The Audio OUT jacks can output the sound of either the main or PIP picture (see "Selecting the Audio OUT sound" on page 49).


\*\* The Video OUT jack will not output a PIP picture.

## Connecting a camcorder

This connection allows you to watch video materials recorded on a camcorder.

You will need:

- one set of standard A/V cables



### **Note:**

If you have an S-VHS camcorder, use an S-video cable instead of a standard video cable.

Do not connect a standard video cable and an S-video cable to Video-3 at the same time or the picture performance will be unacceptable.


## Connecting an audio system

This connection allows you to use an audio amplifier to adjust the audio level. This also allows you to use external speakers.

To control the audio, turn on the TV and the stereo amplifier, and then turn off the built-in speakers (see “Turning off the built-in speakers” on page 48).

You will need:

- one coaxial cable
- one pair of audio cables



### **Note:**

To hear sound, the volume of both the TV and the external audio amplifier must be set above 0 (zero).

The unauthorized recording, use, distribution, or revision of television programs, videotapes, DVDs, and other materials is prohibited under the Copyright Laws of the United States and other countries, and may subject you to civil and criminal liability.


## Connecting an A/V receiver

If you use a system that delivers Dolby Pro Logic\* surround sound, you may want to use the TV speakers as center channel speakers.

A center channel speaker adds to the realism of a surround sound system such as Dolby Pro Logic.

You will need:

- one coaxial cable
- one set of standard A/V cables
- one audio cable for audio center channel



### Caution:

To avoid damaging the TV speakers:

- Turn off the TV before connecting or disconnecting the Audio Center Channel cable.
- Do not connect from the A/V receiver's Center Speaker OUT (amplified signal) to the TV's Audio Center Channel IN.

### Note:


For surround sound system setup details, refer to the instructions provided with your A/V receiver.

When the Audio Center Channel ON/OFF switch is in the ON position, the TV speakers will function only as center channel speakers. At this time, the SBS feature should be set to OFF. See page 48.

To adjust the center channel speaker volume, use the center level control on your A/V receiver.

To use the TV speakers as normal speakers, set the Audio Center Channel ON/OFF switch to the OFF position.

### Dolby Pro Logic\* surround sound system connection example



\* "Dolby Pro Logic" is a registered trademark of Dolby Laboratories Licensing Corporation.

## Using the remote control

### Preparing the remote control for use

Your Toshiba remote control has one dedicated TV mode and 5 universal modes: VCR, Cable/SAT, DVD, Audio1, and Audio2. The target devices and default devices being programmed for each mode are as follows:

Target device/Mode mapping

Mode	Device
TV	Toshiba TV
CABLE/SAT	Universal Cable, Satellite
VCR	Universal VCR, DVD, LD, Cassette
DVD	Universal DVD, VCR, LD, Cassette
AUDIO1	Universal Audio: Amp., Tuner, Misc.Audio, CD/MD
AUDIO2	Universal Audio: CD/MD, Amp., Tuner, Misc.Audio

Default device codes


Mode	Default device
TV	Toshiba TV
CABLE/SAT	Toshiba Satellite receiver
VCR	Toshiba VCR
DVD	Toshiba DVD
AUDIO1	Pioneer Audio receiver
AUDIO2	Pioneer LD

Repeatedly press MODE to cycle among the modes. If you own different brands of audio/video devices and want to operate them using the TV remote control, you must first program the remote control (see “Programming the remote control for use with audio/video devices” on page 16).


### Installing the remote control batteries

To install the batteries:

1. Slide the battery cover off the back of the remote control.




2. Install two “AA” size alkaline batteries. Match the + and - signs on the batteries to the signs on the battery compartment.



3. Slide the battery cover back on to the remote control until the lock snaps.

#### Note:

The remote control may not operate your audio/video devices. Refer to the owner's manuals provided with your other devices to see which features are available. In addition, the remote controls for your other devices may have features not available on the TV remote control. If you would like to continue to use these features, you may want to use the remote controls for your other devices.



#### Caution:

- Dispose of batteries in a designated disposal area. Do not throw batteries into a fire.
- Do not mix battery types, or combine used batteries with new ones.
- Remove dead batteries immediately to prevent battery acid from leaking into the battery compartment.
- Battery life expectancy is about one year with normal use. If you do not intend to use the remote control for a long time, remove the batteries.



# Remote control functional key chart

Key Label	Toshiba TV (TV)	Cable (CBL/SAT)	Satellite (CBL/SAT)	VCR	DVD/LD	Receiver (AUDIO)	CD/MD (AUDIO)	Cassette (VCR)
LIGHT	Illuminates the remote							
SLEEP	Sleep timer	---	---	---	---	---	---	---
POWER	Power	Power	Power	Power	Power	Power	Power	Power
1/MOVIE	Digit 1	Digit 1	Digit 1	Digit 1	Digit 1	AV input 1	Digit 1	Digit 1
2/SPORTS	Digit 2	Digit 2	Digit 2	Digit 2	Digit 2	AV input 2	Digit 2	Digit 2
3/NEWS	Digit 3	Digit 3	Digit 3	Digit 3	Digit 3	AV input 3	Digit 3	Digit 3
4/SERVICES	Digit 4	Digit 4	Digit 4	Digit 4	Digit 4	AV input 4	Digit 4	Digit 4
5/LIST	Digit 5	Digit 5	Digit 5	Digit 5	Digit 5	CD	Digit 5	Digit 5
6	Digit 6	Digit 6	Digit 6	Digit 6	Digit 6	Tuner	Digit 6	Digit 6
MODE	Device mode selection for the remote control							
PIC SIZE	This button is not available for this TV model or any other device connected to this TV.							
7	Digit 7	Digit 7	Digit 7	Digit 7	Digit 7	Phono	Digit 7	Digit 7
8	Digit 8	Digit 8	Digit 8	Digit 8	Digit 8	Cassette	Digit 8	Digit 8
9	Digit 9	Digit 9	Digit 9	Digit 9	Digit 9	Aux	Digit 9	Digit 9
ACTION	---	Menu	Action, Menu	Menu	Menu	---	---	---
100/-	100	100	100	100	100	100	100	100
0	Digit 0	Digit 0	Digit 0	Digit 0	Digit 0	Digit 0	Digit 0	Digit 0
ENT	---	CH Enter	CH Enter	CH Enter	---	---	---	---
GUIDE/SETUP	---	Guide	Guide	Program	DVD setup	Program	Program	---
INFO/TITLE	TV preview	← TV	INFO	← TV	TITLE= Top menu	← TV	← TV	← TV
FAVORITE/ SUBTITLE	Favorite CH	---	Favorite CH	---	Subtitle	---	---	---
ALPHASORT/ AUDIO	---	---	Alphasort	---	Audio	---	---	---
MENU/ ENTER	Menu open/ Enter	Select	Select	Enter	Enter	---	---	---
▲▼	Menu select	Menu select	Menu select	Menu select	Menu select	---	---	---
◀▶/FAV FAV ▶▶	Menu select/ FAV ▶▶	Menu select	Menu select	Menu select	Menu select	---	---	---
VOL ▲▼	Volume up/down*	Volume up/down*	Volume up/down*	Volume up/down*	Volume up/down*	Volume up/down*	Volume up/down*	---
EXIT/ DVD CLEAR	Exit	Exit	Exit	Exit	DVD clear	Exit/Clear	Exit/Clear	Exit/Clear
CH ▲▼	Channel up/down	Channel up/down	Channel up/down	Channel up/down	---	Channel up/down	---	---
INPUT	TV/Video select	← TV	← TV	VCR input	← TV	Input	← TV	← TV
MUTE	Sound mute*	Sound mute*	Sound mute*	Sound mute*	Sound mute*	Sound mute*	Sound mute*	---
RECALL	On-screen display	On-screen display	On-screen display	On-screen display	On-screen display	---	---	---
CH RTN/ DVD RTN	Previous channel	Previous channel	Previous channel	Previous channel	DVD return	---	---	---
SLOW/ DIR ▶ ◀	---	---	---	Forward ---	Forward Reverse	---	---	---
SKIP/ SEARCH ▶ ◀	---	---	---	---	Forward Reverse	CH forward CH reverse	Forward Reverse	Forward Reverse
REW	VCR →	VCR →	VCR →	Rewind	Rewind	Rewind	Rewind	Rewind
PAUSE/STEP	VCR →	VCR →	VCR →	Pause	Pause	Pause	Pause	Pause
PLAY	VCR →	VCR →	VCR →	Play	Play	Play	Play	Play
FF	VCR →	VCR →	VCR →	F. Forward	F. Forward	F. Forward	F. Forward	F. Forward
TV/VCR	VCR →	Bypass A/B	TV/SAT	TV/VCR	---	---	---	---

DISC AM/FM	---	---	---	---	Disc shift	AM/FM	Disc shift	Deck side A/B switch
STOP	VCR →	VCR →	VCR →	Stop	Stop	Stop	Stop	Stop
REC	VCR →	VCR →	VCR →	Record	---	Record	Record	Record
PIP CH ▲▼	PIP channel up/down	← TV	← TV	← TV	← TV	← TV	← TV	← TV
PIP	PIP on/off	← TV	← TV	← TV	← TV	← TV	← TV	← TV
MULTI	Strobe	← TV	← TV	← TV	← TV	← TV	← TV	← TV
STILL	PIP Still	← TV	← TV	← TV	← TV	← TV	← TV	← TV
SWAP	PIP Swap	← TV	← TV	← TV	← TV	← TV	← TV	← TV
LOCATE	PIP Locate	← TV	← TV	← TV	← TV	← TV	← TV	← TV
SOURCE	PIP Source	← TV	← TV	← TV	← TV	← TV	← TV	← TV


**Notes:**

- “---” will send nothing.
- “← TV” will jump to TV.
- “VCR →” will jump to last active VCR or DVD. Active VCR/DVD is defined as the mode that remains for a minimum of 5 seconds, or if a key is pressed in that mode.
- \* The VOLUME and MUTE will jump to “TV” by default. When the volume is unlocked, all the devices will have their own volume. The AUDIO1/2 (Receiver, CD) modes will have their own volume even if Volume Lock is on TV, CABLE/SAT, VCR, or DVD. See “Using the Volume Lock feature” on page 17.

## Programming the remote control for use with your audio/video devices

### Device code setup

1. Refer to the Device code table on pages 18–21 to find the code for the brand of your device.  
If more than one code is listed, try each one separately until you find the one that works.
2. Press MODE until the Mode indicator of the device (CABLE/SAT, VCR, DVD, AUDIO1, AUDIO2) lights up.
3. While holding down RECALL, press the Number buttons to enter the four-digit code for your device.  
If the correct code is entered, the mode indicator will blink twice.  
If an incorrect code is entered, there will be one long blink.
4. Point the remote control at the device and press POWER to test the code.  
If the device responds to the remote control, you have entered the correct code.  
If the device does not respond, you may have entered the wrong code. Repeat steps 3 and 4 using another code.
5. To control the TV, press MODE to select TV.



### Note:

- Each time you replace the batteries, you must reprogram the remote control.
- Some newer VCRs are capable of working on either of two remote codes. These VCRs have a switch labeled "VCR1/VCR2."

If your VCR has this kind of switch and does not respond to any of the codes for your VCR brand, set the switch to the other position (VCR1 or VCR2) and reprogram the remote control.

### Searching and sampling the code of a device (991)

If you do not know the device code for a particular device, you can cycle the remote control through the available codes for that device mode, and sample various function buttons to find the code that enables the remote control to operate the target device. The keys available to be sampled, provided they are applicable to that mode, are 0, 1, 2, 3, POWER, VOL ▲, CH ▲, PLAY, and STOP. Invalid keys will be ignored while in program mode.

To cycle through each available device code and sample its functions:

1. Press MODE to select the mode you want to set up.
2. While holding down RECALL, press 9, 9, 1. The remote control will enter program mode.
3. Point the remote control at the target device, and then press POWER (or other function buttons that are available to be sampled).
4. If the device responds to the remote control:  
Press RECALL to store the device code. The mode indicator will blink twice, and the remote control will exit program mode.

If the device does not respond to the remote control:  
Press MENU ▲, and then press POWER. Repeat this step until the device responds to the remote control, and then press RECALL.

**Note:** When the search cycle is done, the mode indicator will blink three times. The remote control will begin to cycle through the available codes again. If no key is pressed within 10 seconds while programming, the remote control will exit the program mode and return to the previous code.

## Verifying the device code (990)

Use this feature to verify the device codes currently programmed in the remote control. The number of blinks after pressing the 1, 2, 3, and 4 buttons is the 4-digit code set up for that mode.

For example, to verify the device code for the VCR mode:

1. Repeatedly press MODE until the VCR mode is selected.
2. While holding down RECALL, press 9, 9, 0.
3. Press 1 → 0 blinks.
4. Press 2 → 3 blinks.
5. Press 3 → 8 blinks.
6. Press 4 → 5 blinks.

This verifies that the device code of the VCR mode is “0385.”

## Using the Volume Lock feature (993)

For the TV, CABLE/SAT, VCR, and DVD modes, the volume controls (VOL ▲▼ and MUTE) can be programmed or locked to the selected device mode. This feature does not apply to the AUDIO1 and AUDIO2 modes.

For example, to lock the volume controls to the CABLE/SAT mode:

1. Repeatedly press MODE until the CABLE/SAT mode is selected.
2. While holding down RECALL, press 9, 9, 3.
3. Press VOL ▲. When locked, the mode indicator will blink two times.

The following table describes in more detail the Volume Lock implementation.

Volume locked to:	TV	CBL/SAT	VCR	DVD	AUD1	AUD2
TV (default)	TV	TV	TV	TV	AUD1	AUD2
CBL/SAT	CBL/SAT	CBL/SAT	CBL/SAT	CBL/SAT	AUD1	AUD2
VCR	VCR	VCR	VCR	VCR	AUD1	AUD2
DVD	DVD	DVD	DVD	DVD	AUD1	AUD2
AUD1	AUD1	AUD1	AUD1	AUD1	AUD1	AUD1
AUD2	AUD2	AUD2	AUD2	AUD2	AUD2	AUD2

To reset the volume controls to the original device code:


1. While holding down RECALL, press 9, 9, 3.
2. Press VOL ▼. When unlocked, the mode indicator will blink four times.

## Operational feature reset (980)

This feature clears all setup features not related to “Device code set up,” and resets the Volume Lock to “TV.”

To reset the features:

- While holding down RECALL, press 9, 8, 0.
- When reset, the mode indicator will blink two times, and then pause and blink two more times.



## Device code table

## Cable box setup codes

Brand name	Code number	Brand name	Code number
ABC	0020, 0022, 0026, 0027, 0030, 0032, 0033, 0036	SL Marx	0059
Allegro	0172, 0334	Samsung	0059, 0163
Americast	0918	Scientific Atlanta	0027, 0036, 0496, 0896
Antronix	0041, 0226	Seam	0529
Archer	0041, 0172, 0226, 0816	Signal	0034, 0059
BBT	0286	Signature	0030
Belcor	0075	Sprucer	0040
Bell & Howell	0033	StarSight	0441, 0561
Bell South	0918	Starcom	0022, 0034
Cable Star	0075	Stargate	0034, 0059, 0789, 0816
Cabletenna	0041	Starquest	0034
Cableview	0041	Sylvania	0020
Century	0172	TFC	0329
Citizen	0172, 0334	TV86	0082
Colour Voice	0044, 0050	Tandy	0277
Comtronics	0059	TeleCaption	0240
Contec	0038	Televue	0059
Digi	0656	Texscan	0020
Eastern	0021	Timeless	0437
Emerson	0816	Tocom	0031, 0032
Everquest	0034, 0059	Toshiba	0019
Focus	0419	Tusa	0034
GC Electronics	0075, 0226	Unika	0041, 0172, 0226
Garrard	0172	United Artists	0026
Gemini	0034, 0089, 0816	Universal	0041, 0075, 0172, 0210, 0226
General Instrument	0030, 0295, 0495, 0829	Viewstar	0046, 0082, 0277
GoldStar	0059, 0163	Zenith	0019, 0073, 0544, 0918
Goodmind	0816	Zentek	0419
Hamlin	0028, 0039, 0053, 0278, 0292		
Hitachi	0030		
Hytex	0026		
Jasco	0034, 0172, 0334		
Jerrold	0022, 0030, 0031, 0033, 0034, 0043, 0295, 0495, 0829		
Linsay	0459		
Magnavox	0046		
Memorex	0019		
Movie Time	0082, 0175		
NSC	0082, 0089, 0175		
Novaplex	0637		
Oak	0026, 0038		
Optimus	0040		
Panasonic	0019, 0040, 0126		
Panther	0656		
Paragon	0019		
Philips	0044, 0046, 0050, 0172		
Pioneer	0042, 0163, 0552, 0896		
Popular Mechanics	0419		
Prelude	0789		
Pulsar	0019		
Quasar	0019		
RCA	0040		
Radio Shack	0034, 0334, 0816, 0902		
Realistic	0226		
Recoton	0419		
Regal	0039, 0278, 0292		
Regency	0021		
Rembrandt	0030, 0089		
Runco	0019		

## Satellite Receiver setup codes

Brand name	Code number
AlphaStar	0791
Chaparral	0072, 0235
Curtis Mathes	0080
Echostar	0288, 0299, 0794, 1024
Expressvu	0794
General Instrument	0380, 0646, 0888
HTS	0794
Hitachi	0838
Homecable	0257
Hughes Network Systems	0768
IQ	0229
IQ Prism	0229
JVC	0794
Jerrold	0380, 0646
Legend	0288
Macom	0080
Magnavox	0741, 0743
Memorex	0288, 0743
Next Level	0888
Panasonic	0720
Philips	0741, 0743
Primestar	0380, 0646
RCA	0162, 0411, 0585, 0874
Radio Shack	0888
Realistic	0071
STS	0229
Sony	0658
Star Choice	0888
Toshiba	0080, 0101, 0768, 0809, 1071, 1072, 1073
Uniden	0071, 0093, 0257, 0741, 0743
Zenith	0080, 0875



## Device code table

### VCR setup codes

Brand name	Code number				
Admiral	0067, 0228	Kenwood	0057, 0060, 0086,	Radix	0056
Adventura	0019		0403	Randex	0056
Aiko	0297	Kodak	0054, 0056	Realistic	0019, 0054, 0056,
Aiwa	0019, 0056, 0326	LXI	0056		0065, 0066, 0067,
Akai	0060, 0072, 0080,	Lloyd's	0019, 0227		0081, 0085, 0123
	0125	Logik	0091	ReplayTV	0633, 0635
America Action	0297	MEI	0054	Ricoh	0053, 0272
American High	0054	MGA	0062, 0080, 0259	Runco	0058
Asha	0259	MGN Technology	0259	STS	0061
Audiovox	0056	MTC	0019, 0259	Samsung	0064, 0070, 0072,
Beaumark	0259	Magnasonic	0297		0259
Bell & Howell	0123	Magnavox	0019, 0054, 0058,	Sanky	0058, 0067
Broksonic	0021, 0140, 0203,		0100, 0129, 0168	Sansui	0019, 0060, 0086,
	0228, 0314, 0380,	Magnin	0259		0228, 0290, 0498
	0498	Marantz	0054, 0100	Sanyo	0065, 0066, 0123,
CCE	0091, 0297	Marta	0056		0259
Calix	0056	Matsushita	0054, 0181, 0473	Scott	0062, 0064, 0140,
Canon	0054	Memorex	0019, 0054, 0056,		0203, 0229, 0231
Capehart	0039		0058, 0065, 0066,	Sears	0019, 0054, 0056,
Carver	0100		0067, 0123, 0181,		0061, 0065, 0066,
Cineral	0297		0228, 0259, 0326,		0073, 0076, 0085,
Citizen	0056, 0297		0473, 1056, 1181,		0123, 0124
Colt	0091		1281	Semp	0064
Craig	0056, 0066, 0091,	Minolta	0061, 0124	Sharp	0067, 0081
	0259, 0290	Mitsubishi	0062, 0067, 0080,	Shintom	0091
			0086	Shogun	0070, 0259
Curtis Mathes	0054, 0060, 0079,	Motorola	0054, 0067	Singer	0091
	0181	Multitech	0019, 0091	Sony	0019, 0051, 0052,
Cybernex	0070, 0259	NAD	0077		0053, 0054, 0272,
Daewoo	0039, 0064, 0297,	NEC	0057, 0059, 0060,		1051
	0580		0086, 0123	Sunpak	0272
Daytron	0039		0056	Sylvania	0019, 0054, 0062,
Denon	0061	Nikko	0053, 0272		0100, 0129
Dynatech	0019	Nikon	0259	Symphonic	0019
Electrohome	0056	Noblex	0259	TMK	0055, 0227, 0259
Electrophonic	0056	Olympus	0054	Tatung	0060
Emerex	0051	Optimus	0056, 0067, 0077,	Teac	0019, 0060
Emerson	0019, 0021, 0055,		0123, 0181, 0451,	Technics	0054, 0181
	0056, 0062, 0080,		0473, 1067, 1081,	Teknika	0019, 0054, 0056
	0087, 0107, 0140,		1181, 1281	Thomas	0019
	0203, 0227, 0228,	Optonica	0081	Tivo	0637
	0231, 0297, 0313,	Orion	0021, 0203, 0228,	Toshiba	0062, 0064, 0076,
	0314, 0380, 0498,		0314, 0498		0085, 0229, 0231,
	0580	Panasonic	0054, 0096, 0181,		0385
Fisher	0066, 0073, 0085,		0244, 0473, 0635,	Totevision	0056, 0259
	0123		1081, 1181, 1281	Unitech	0259
Fuji	0052, 0054	Penney	0054, 0056, 0057,	Vector	0064
Funai	0019		0059, 0061, 0073,	Vector Research	0057, 0059
GE	0054, 0067, 0079,		0259	Video Concepts	0059, 0064, 0080
	0221, 0259	Pentax	0061, 0124	Videosonic	0259
Garrard	0019	Philco	0054, 0228, 0498	Wards	0019, 0054, 0061,
Go Video	0451, 0545, 0662	Philips	0054, 0081, 0100,		0066, 0067, 0079,
GoldStar	0056, 0057		0129, 0637, 1100,		0081, 0091, 0100,
Gradiente	0019, 0027		1200		0168, 0231, 0259
HI-Q	0066	Pilot	0056	White Westinghouse	0228, 0297
Harley Davidson	0019	Pioneer	0077, 0086	XR-1000	0019, 0054, 0091
Harman/Kardon	0057, 0100	Portland	0039	Yamaha	0057
Harwood	0087, 0091	Profitronic	0259	Zenith	0019, 0052, 0053,
Headquarter	0065	Proscan	0079, 0221		0058, 0228, 0498,
Hitachi	0019, 0060, 0061,	Protec	0091		0656
	0124	Pulsar	0058, 0070		
Hughes Network		Quarter	0065		
Systems	0061	Quartz	0065		
JVC	0027, 0060, 0086,	Quasar	0054, 0096, 0181,		
	0403		0473, 1181		
Jensen	0060	RCA	0054, 0061, 0067,		
KEC	0056, 0297		0079, 0096, 0124,		
KLH	0091		0125, 0168, 0221,		
			0259		
		Radio Shack	0019, 1056		

Introduction

Connecting  
your TV

Using the  
Remote Control

Setting up  
your TV

Using the TV's  
Features

Appendix

Device code table

DVD setup codes		CD Player setup codes			
Brand name	Code number	Brand name	Code number		
Aiwa	0660	ADC	0037	Sanyo	0106, 0198
Denon	0509, 0653	Adcom	0174, 0253	Scott	0174, 0183, 0324
GE	0541	Aiwa	0143, 0176	Sears	0324
Harman/Kardon	0601	Akai	0175	Sharp	0056, 0199, 0880
JVC	0577, 0642	Audio Alchemy	0213	Sherwood	0199, 0215, 0445, 1086
Kenwood	0553	Audio-Technica	0189	Sony	0019, 0204, 0509, 0623, 0624
Magnavox	0522	BSR	0213, 0264	Soundesign	0164
Marantz	0558	Burmester	0439	Tascam	0439
Mitsubishi	0540	California Audio Labs	0048, 0322	Teac	0193, 0199, 0412, 0439
Onkyo	0522, 0646	Carrera	0213	Technics	0048, 0322
Optimus	0590	Carver	0176, 0198, 0318, 0456	Toshiba	0038, 0318
Panasonic	0509, 0651	DAK	0264	Vector Research	0213
Philips	0522, 0558	DKK	0019	Victor	0091
Pioneer	0544, 0590, 0651	Denon	0022, 0892	Wards	0072, 0176
Proscan	0541	Emerson	0174, 0183, 0324, 0488	Yamaha	0055, 0189, 0206
RCA	0541	Fisher	0107, 0193, 0198, 0361	Yorx	0480
Samsung	0592	GE	0028		
Sharp	0649	Garrard	0264, 0299, 0412, 0439		
Sherwood	0652	Genexxa	0051, 0183, 0324		
Sony	0552	Harman/Kardon	0176, 0192, 0445		
Technics	0509	Hitachi	0051, 0174		
Theta Digital	0590	JVC	0091		
Toshiba	0522	Kenwood	0047, 0056, 0209, 0645, 0700, 0845		
Yamaha	0509, 0564	Kodak	0306		
Zenith	0522, 0610	Krell	0176		
Laser Disc setup codes		Kyocera	0037		
Brand name	Code number	LXI	0324		
Aiwa	0222	Linn	0176		
Carver	0083, 0213, 0342	Luxman	0112		
Denon	0078, 0191	MCS	0048		
Disco Vision	0042	MTC	0439		
Funai	0222	Magnavox	0176, 0324		
Harman/Kardon	0213	Marantz	0048, 0176, 0199		
Hitachi	0042	McIntosh	0306		
Magnavox	0213, 0236	Mission	0176		
Marantz	0083, 0213	NAD	0038, 0318		
Mitsubishi	0078	NEC	0253		
NAD	0078	NSM	0176		
Optimus	0078	Nikko	0183, 0189, 0193		
Panasonic	0223	Onkyo	0120, 0887		
Philips	0083, 0213	Optimus	0019, 0051, 0056, 0106, 0164, 0198, 0213, 0215, 0299, 0324, 0361, 0439, 0445, 0456, 0487, 1082		
Pioneer	0042, 0078	Panasonic	0048, 0322, 0386, 0771		
Quasar	0223	Parasound	0213, 0439		
Realistic	0222	Philips	0176, 0306, 0645		
Samsung	0342	Pioneer	0051, 0263, 0324, 0487, 1082		
Sega	0042	Proton	0176		
Sony	0212, 0220	QED	0176		
Technics	0223	Quasar	0048		
Theta Digital	0213	RCA	0028, 0072, 0174, 0198, 0324, 0783		
Yamaha	0236	Realistic	0174, 0183, 0198, 0199, 0439		
		Rotel	0176, 0439		
		SAE	0176		
		STS	0037		
		Sansui	0176, 0221, 0324		

## Device code table

### Amplifier setup codes

Brand name	Code number
Aiwa	0425
Carver	0288
Curtis Mathes	0319
Denon	0179
GE	0097
Harman/Kardon	0911
JVC	0350
Linn	0288
Magnavox	0288
Marantz	0288
Optimus	0319, 0414
Panasonic	0327
Philips	0288, 0911
Pioneer	0032, 0319
Realistic	0414
Sony	0239, 0708
Soundesign	0097
Technics	0327
Toshiba	0372
Victor	0350
Wards	0032, 0097
Yamaha	0373

### Cassette Player setup codes

Brand name	Code number
Aiwa	0048, 0216, 0219
Akai	0302
Carver	0048
Denon	0095
Fisher	0093
Garrard	0327, 0458
Harman/Kardon	0048, 0201
JVC	0263, 0292
Kenwood	0089
Magnavox	0048
Marantz	0028, 0048
Mitsubishi	0302
Onkyo	0154, 0155, 0301
Optimus	0046, 0239, 0356, 0458
Panasonic	0248
Philips	0048
Pioneer	0046, 0118, 0239
Revox	0209
Sansui	0028, 0048
Sherwood	0356
Sony	0189, 0262, 0310
Teac	0327
Technics	0248
Toshiba	0360, 0361
Victor	0292
Wards	0046
Yamaha	0113, 0116

### Misc. Audio setup codes

Brand name	Code number
Aiwa	0029, 0178, 0423
Fisher	0071
Harman/Kardon	0496
JBL	0496
JVC	0092
Jerrold	0478, 0539
Nikko	0395
Paramount Pictures	0336
RCA	0075
SSI	0336
Schneider	0395
Scientific Atlanta	0479
Sony	0029, 0178, 0595
Soundesign	0395
Starcom	0478
Yorx	0395

### Receiver setup codes

Brand name	Code number
ADC	0550
Adcom	0635
Aiwa	0140, 0177, 0208, 0424, 1108, 1424
Akai	0095, 0243
Capetronic	0550
Carver	0027, 0061, 0208, 0379, 1108, 1208
Casio	0214
Clarinet	0214
Curtis Mathes	0099
Denon	0023, 0292, 0790, 1123, 1179
Emerson	0443
Fisher	0061, 0238, 0379
Garrard	0443, 0482
Harman/Kardon	0129, 0208, 0910
Inkel	0081
JBL	0129
JVC	0093
Kenwood	0046, 0061, 0096, 0205, 0332, 0333, 1046, 1071, 1332, 1588
Koss	0443
LXI	0200
Linn	0208
Lloyd's	0214
MCS	0058, 0365
Magnavox	0147, 0208, 0214, 0410, 0550, 1108, 1208
Marantz	0058, 0147, 0208, 1108, 1208
Modulaire	0214
NAD	0339
NEC	0254
Nakamichi	0116, 0366
Onkyo	0119, 0154, 0399
Optimus	0061, 0099, 0196, 0200, 0205, 0238, 0550, 0689, 0757, 0820, 1042
Panasonic	0058, 0328, 0537, 1537
Penney	0214
Philips	0208, 0410, 1108, 1208

Pioneer	0033, 0099, 0169, 0550, 0649, 1042
Proscan	1273
Quasar	0058
RCA	0073, 0365, 0379, 0549, 0550, 1173, 1273
Realistic	0182, 0200, 0214
Sansui	0208, 0212, 0365, 1108
Sanyo	0238, 0820
Scott	0182, 0341
Sharp	0205
Sherwood	0081, 0510, 0521
Sony	0177, 0187, 0493, 1061, 1077, 1177, 1277
Soundesign	0689
Sunfire	0332, 0333, 1071, 1332
Teac	0182, 0482
Technics	0058, 0227, 0328, 0537, 1327, 1328, 1537
Thorens	1208
Victor	0093
Wards	0033, 0073, 0099, 0177, 0208
Yamaha	0195, 0205, 1195
Yorx	0214
Zenith	0876

Introduction

Connecting  
your TV

Using the  
Remote Control

Setting up  
your TV

Using the TV's  
Features

Appendix

## Learning about the remote control

Only the buttons used to operate the TV are described here.

**POWER** turns the TV on and off

**SLEEP** programs the TV to turn off at a specific time (page 44)

**LIGHT** Pressing the LIGHT button toggles the illumination mode on and off. With the illumination mode on, the keypad will light up for 5 seconds when any key is pressed. (If in programming mode, the keypad will remain lit for 10 seconds).

**Channel Numbers (0–9, 100)** allow direct access to channels, even those not programmed into the TV's memory (page 26)

**MODE** cycles through the six device modes (TV, CABLE/SAT, VCR, DVD, AUDIO1, and AUDIO2). The mode indicator light will remain lit for 10 seconds.

**FAVORITE** accesses the multi-window favorite channel scan function (page 33)

**INFO** accesses the multi-window channel preview function (page 33)

**MENU/ENTER** accesses the on-screen menu system and sets menu information (page 23)

**▲▼◀▶ Buttons** select or adjust menu items when a menu is on-screen (page 23)

**◀▶ Buttons** cycle through only the channels you program as favorite channels. These buttons function as favorite channel buttons (FAV ◀▶) only when no menu is on-screen. (page 28)

**VOL ▲▼** adjusts the volume level

**EXIT** closes any open on-screen menu (page 23)

**CH ▲▼** cycles through only the channels you program into the TV's memory) (page 26)

**CH RTN** returns to the last viewed channel (page 28)

**RECALL** displays TV status information on-screen (page 50)

**MUTE** dims (1/2 mutes) or turns off (mutes) the sound (page 45)

**INPUT** selects the video input source (page 42)

**PIP Buttons** access PIP functions (page 31)

**PIP** turns the PIP feature on and off

**PIP CH ▲▼** changes the PIP channel


**MULTI** accesses the multi-window strobe function

**STILL** freezes the PIP picture

**SOURCE** selects the PIP source

**LOCATE** moves the PIP window

**SWAP** swaps the main and PIP pictures




## Setting up your TV

### Learning about the menu system


After you have installed the batteries and programmed the remote control, you will need to set some preferences on the TV using the menu system. You can access the menus using the buttons on the TV or remote control.

1. Press MENU to display the menu system.
2. Press ◀ or ▶ to select a menu.
3. Press ▲ or ▼ to select an item.
4. Press ◀ or ▶ to select or adjust a setting.




- Press ENTER to activate the function settings in the SET UP menu.
- Main menus close automatically if no selection is made within 15 seconds; sub-menus close automatically within 6 seconds (except the Convergence menu, which remains open until a button is pressed).
- Press EXIT to close an on-screen menu instantly.

TV front panel



MENU ▲▼▶◀ EXIT



#### Note:

You can change the background of the menus. See page 50 for details.




## Changing the on-screen display language

You can choose from three different languages (English, French and Spanish) for the on-screen displays. Adjustment menus and messages will appear in the language of your choice.

To select an on-screen display language:

1. Press **MENU**, and then press ◀ or ▶ until the **SET UP** menu appears.
2. Press ▲ or ▼ to highlight **LANGUAGE**.




3. Press ◀ or ▶ to highlight your desired language.

## Selecting the antenna input


You can monitor or change the signal source that is connected to the TV (ANT 1, VIDEO 1, VIDEO 2, VIDEO 3, ColorStream, or ANT 2). The current signal source will display in purple.

To select the antenna input:

1. Press the **INPUT** button on the remote control (see below left) or the **TV/VIDEO** button on the TV front panel (see below right) to select either ANT 1 or ANT 2.




Pressing **INPUT** on the remote control displays this screen. To select, press 0–5.




Pressing **TV/VIDEO** on the TV displays this screen. To select, press **TV/VIDEO**.

To use the menu system to select the antenna input:


1. Press **MENU**, and then press ◀ or ▶ to highlight the **SET UP** menu.
2. Press ▲ or ▼ to highlight **ANT 1/2**.



3. Press ◀ or ▶ to highlight either ANT 1 or ANT 2.



TV front panel



## Adding channels to the TV's memory


When you press Channel ▲▼, the TV will cycle through only the channels stored in the TV's channel memory. Use the steps below and on the next page to program channels into the TV's memory.

### Programming channels automatically


The TV can automatically detect all active channels in your area and store them in its memory. After the TV has automatically stored all active channels, you can manually add or erase individual channels. If you use both ANT-1 and ANT-2 terminals, you must program channels for each input source.

To automatically program channels into the TV's memory:

1. Press MENU, and then press ◀ or ▶ until the SET UP menu appears.
2. Press ▲ or ▼ until TV/CABLE is highlighted.
3. Press ◀ or ▶ to highlight TV (if you use an antenna) or CABLE (if you use cable).




4. Press ▲ or ▼ to select CH PROGRAM.



5. Press ◀ or ▶ to start automatic channel programming. The TV automatically cycles through all of the channels (either TV or cable, depending on which you selected), and stores all active channels in its memory.

While the TV is cycling through the channels, the message "Programming Now—Please Wait" appears.

6. When channel programming is complete, the message "Completed" appears.
7. Press Channel ▲▼ to view the programmed channels.




## Adding and erasing channels manually


After you have automatically programmed channels into the TV's memory (see page 25), you can manually add or erase individual channels.

To manually add or erase channels:

1. Select the channel you want to add or erase. If you are adding a channel, you must use the Channel Number buttons to select the channel.
2. Press MENU, and then press ◀ or ▶ until the SET UP menu appears.
3. Press ▲ or ▼ to highlight ADD/ERASE.



4. Press ◀ or ▶ to select ADD or ERASE, whichever function you want to perform.
5. Repeat steps 1–4 for other channels you want to add or erase.




## Changing channels

To change to the next programmed channel:

Press Channel ▲▼ on the TV or remote control.

To change to a specific programmed channel:

Press and hold Channel ▲▼ for about one second. The TV will enter the channel surf mode.



Repeatedly press or hold Channel ▲ or ▼ while the channel surf mode is on-screen to scroll the channel list. Release the button to display the highlighted channel.

To change to a specific channel (programmed or unprogrammed):

Press the Channel Number buttons (0–9 and 100).

For channels 100 and higher, press the 100 button, and then the next two numbers. For example, to select channel 125, press 100, 2, 5.


## Adjusting the color convergence

This projection TV uses three separate TV tubes: red, green, and blue. The red, green, and blue images are projected onto the screen where they converge to form a full-color picture. You can see a clear picture only when the three images converge correctly. Convergence may drift over time or if you move the TV. (If the image on your screen is clear, skip this procedure.)


To adjust the color convergence:

**Note:** The TV must be on for at least 30 minutes before adjusting the color convergence.


1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▲ or ▼ to highlight CONVERGENCE (below left).
3. Press ◀ or ▶ to display the center CONVERGENCE menu (below right). If you see separate red, blue, or green crossed lines, you should adjust the convergence.



4. Press ENTER to highlight RED or BLUE, depending on which color needs adjusting. If both red and blue need adjusting, you must perform steps 4 and 5 twice.
5. Press ▲ (up), ▼ (down), ◀ (left), or ▶ (right) on the remote control to converge the red or blue line into the green line. When correctly adjusted, you will see two single crossed white lines.
6. Press EXIT to display the circumference CONVERGENCE menu.
7. Press the corresponding Number button (1–4 and 6–9) to select the area you want to adjust (below left).
8. Press ENTER to highlight RED or BLUE, depending on which color needs adjusting (below right). If both red and blue need adjusting, you must perform steps 8 and 9 twice.



9. Press ▲▼◀▶ to converge the red or blue line into the green line, until you see two single crossed white lines.
10. To select another area to adjust, press EXIT once, and then repeat steps 7 through 9.
11. To close the CONVERGENCE menu, press EXIT twice.










## Switching between two channels








To switch between two channels:

- Each time you press CH RTN, the TV will switch back and forth between the two channels.

You can use the favorite channel programming feature to preset up to 18 of your favorite channels (nine in FAVORITE CH1 and nine in FAVORITE CH2). Because this feature scans through only your favorite channels, it allows you to skip other channels you do not normally watch.

To program your favorite channels:

- 





- 
**CUSTOM**
- TIMER  
 CC OFF  
☒ FAVORITE CH1 ▶  
 FAVORITE CH2 ▶  
 CH LABELING ▶  
 VIDEO LABEL ▶  
 BACKGROUND ▶

- 





- 
**CUSTOM**
- TIMER OFF
- | FAVORITE CH1 | CH        | INPUT | xxx |
|--------------|-----------|-------|-----|
| FAVORITE CH2 | 0         | 0     | 0   |
| CH LABELING  | 0         | 0     | 0   |
| VIDEO LABEL  | 0         | 0     | 0   |
| BACKGROUND   | TV CABLE  |       |     |
|              | CLEAR ALL |       |     |

- Note:** For channels 100 and higher, you must use the 100 button.

5. Press ENTER.
6. Repeat steps 4 and 5 for other channels you want to program as favorite channels.

To select your favorite channels:

Press (FAV) ◀ or ▶.

**Note:** If you press (FAV) ◀ or ▶ when no channels are programmed as favorite channels, the current channel will not change.

To scan your favorite channels in a 9-picture multi-window:

Press FAVORITE (see “Using the favorite function” on page 33).

**Note:** If you press FAVORITE when no channels are programmed as favorite channels, the message "Not Available" will display on-screen.

MENU/  
ENTER

▲▼◀▶  
(FAV) ◀▶

- CH RTN

## Using the TV's Features


**Note:**

- The (FAV) ◀▶ buttons function as menu ◀▶ buttons when a menu is on-screen.
- The favorite channel feature is not available for the ANT2 input.



To clear a favorite channel:


1. Press MENU, and then press ◀ or ▶ until the CUSTOM menu appears.
2. Press ▲ or ▼ to highlight FAVORITE CH2, for example.
3. Press ◀ or ▶ to display the FAVORITE CH2 menu. CH INPUT will be highlighted.
4. Press ▲▼◀▶ to highlight the channel you want to clear, and then press ENTER.



5. Repeat step 4 for other channels you want to clear.

To clear all favorite channels at once:

Press ▲ or ▼ to highlight CLEAR ALL in step 4 above, and then press ▶ or ◀. All listed channel numbers will change to "0."




## Labeling channels


Channel labels appear above the on-screen channel number display each time you turn on the TV, select a channel, or press RECALL. You can choose any four characters for a channel label.

To create a channel label:

1. Press MENU, and then press ◀ or ▶ until the CUSTOM menu appears.
2. Press ▲ or ▼ to highlight CH LABELING.
3. Press ◀ or ▶ to display the CH LABELING menu. CH INPUT will be highlighted.




4. Press the Channel Number buttons to input the channel you want to label.




5. Press ▼ to highlight LABEL.

(Continued on next page)




- Repeatedly press ◀ or ▶ to select a character for the first space, and then press ENTER.




- Repeat step 6 to enter the rest of the characters.  
For a blank space in the label name, select an empty space from the list of characters; otherwise, a dash “—” will appear in that space.
- Repeat steps 4 through 6 for other channels. You can assign labels to a maximum of 32 channels.

To clear a channel label:

- Press MENU, and then press ◀ or ▶ until the CUSTOM menu appears.
- Press ▲ or ▼ to highlight CH LABELING.
- Press ◀ or ▶ to display the CH LABELING menu.
- Press the Channel Number buttons to input the channel number whose label you want to clear.
- Press ▼ to highlight CLEAR.



- Press ◀ or ▶ to clear the channel label.
- To clear other channel labels, press ▲ to highlight CH INPUT, and then repeat steps 4 through 6.




## Watching picture-in-picture (PIP)

The picture-in-picture (PIP) feature allows you to watch two pictures at the same time. The smaller (PIP) picture can come from a TV broadcast or an external source, such as a VCR.


To display a TV broadcast in the PIP window:

1. Turn on the TV and select the program you want to watch.
2. Press PIP once to display a small picture. A window 1/9 the size of the screen will appear. Press PIP a second time to display a 1/16 size window.




3. Press PIP CH ▲▼ to choose the program you want to display in the PIP window.

If the V-CHIP feature is active and you try to watch a TV program that exceeds the rating limits you set, the TV will enter the program block mode. See “Using the V-CHIP menu” on page 35.




To display a picture from an external source in the PIP window:

1. Make sure you have connected the external source equipment properly. For more information, see the “Connecting your TV” on page 7.
2. Turn on the TV and select the program you want to watch.
3. Press PIP once to display a small picture. A window 1/9 the size of the screen will appear. Press PIP a second time to display a 1/16 size window.
4. Repeatedly press SOURCE to select the PIP input source (TV, VIDEO 1, VIDEO 2, or VIDEO 3). The selected source will be displayed in purple. ColorStream cannot be selected.



To turn PIP off:

Press PIP once or twice, depending on the PIP window size you selected.



PIP  
SOURCE  
PIP CH ▲▼

### Note:

- PIP cannot be turned on when ColorStream input is being viewed.
- You cannot display ANT-2 signal sources in the PIP window.
- You can output the sound of either the main or PIP picture from the Audio OUT jacks (see “Selecting the audio OUT sound” on page 49).

### NOTICE OF POSSIBLE ADVERSE EFFECTS ON TV PICTURE TUBE

Avoid displaying stationary images on your TV screen for extended periods of time. Fixed (non-moving) images can become permanently engrained in the picture tube. **This type of damage is NOT COVERED BY YOUR WARRANTY because it is the result of misuse.** See item 32 on page 4.

Introduction

Connecting your TV

Using the Remote Control


Setting up your TV

Using the TV's Features

Appendix


## Switching the main and PIP pictures

Press SWAP while you are using the PIP feature to switch the main and PIP pictures. The main and PIP pictures will switch each time you press the SWAP button.





## Changing the position of the PIP window

Press LOCATE repeatedly while you are using the PIP feature to change the position of the PIP window, in the following order:



## Freezing the PIP picture

Press STILL while you are using the PIP feature to freeze the PIP picture. To return to the moving picture, press STILL again.



### NOTICE OF POSSIBLE ADVERSE EFFECTS ON TV PICTURE TUBE

Avoid displaying stationary images on your TV screen for extended periods of time. Fixed (non-moving) images can become permanently engrained in the picture tube. **This type of damage is NOT COVERED BY YOUR WARRANTY because it is the result of misuse.** See item 32 on page 4.

## Using the multi-window feature

The multi-window feature provides two channel search functions (INFO and FAVORITE) and one strobe function (MULTI).

### Using the multi-window channel preview function


The channel preview function scans the channels you programmed into the TV's memory (pages 23–24) in a 6-picture multi-window across the bottom of the screen.

To start the channel preview function:

Press INFO.

To cancel the channel preview function:

Press INFO again.




### Using the multi-window favorite channel scan function

The favorite channel scan function displays the channels you programmed as favorite channels (page 28) in a 9-picture multi-window.

**Note:** If you press FAVORITE when no channels are programmed as favorite channels, the message "Not Available" will display on-screen.

To start the favorite channel scan function:

1. Press FAVORITE to display the channels you programmed into FAVORITE CH1. (Press FAVORITE a second time to display the channels you programmed into FAVORITE CH2.)  
The 9-picture scan starts, with the first window displaying a moving picture.
2. Press ▲▼◀▶ to highlight the window of the channel you want to watch.
3. Press ENTER to display the channel you selected in step 2 as the main picture.



Each time you press FAVORITE, the displays changes in the following order:

FAVORITE CH1 — FAVORITE CH2 — OFF

To cancel the favorite channel scan function:

Press FAVORITE one or two times, depending on whether you are scanning the FAVORITE CH1 or FAVORITE CH2 channels.

### Using the multi-window strobe function


The strobe function strobes the current picture in a 9-picture multi-window. This function is convenient when watching a quickly moving picture. For example, you can strobe the action of the current TV program or view a decisive moment of a previously recorded sports program.

To start the strobe function:

Press MULTI.

To cancel the strobe function:

Press MULTI again.



#### Notes:


- When the main picture source is ColorStream, the INFO, FAVORITE, and MULTI functions are not available.
- The INFO button will not work when ANT 2 mode is selected.
- A program or channel you blocked in the LOCKS menu may not be blocked during INFO or FAVORITE multi-window scanning. When blocked properly, the program will appear as a black window with an "X" under the channel number.

## Using the LOCKS menu

The LOCKS menu includes the V-CHIP, CH Lock, Video Lock, and New PIN Code functions. You can use these functions after entering the correct PIN code.


### Entering the PIN code

1. Press MENU, and then press ◀ or ▶ until the LOCKS menu appears.



2. Press ▲ or ▼ to display the PIN code entering mode.

- Blocking reset status:  
Press the Number buttons (0–9) to enter a new 4-digit PIN code, and then press ENTER.
- When the PIN code is already stored:  
Press the Number buttons (0–9) to enter your existing PIN code, and then press ENTER.




If the wrong PIN code is entered, the message “Incorrect” displays. Enter the code again, and then press ENTER.

### If you cannot remember your PIN code.

While the PIN code entering screen is displayed, press RECALL four times within 5 seconds. The PIN code will be released (blocking reset status restored).

Continue to set each item following the steps on the next page.





## Using the V-CHIP menu

Some TV programs and movies include signals that classify the content of the program (violence, sex, dialog, language). The V-CHIP control feature in this TV detects the signals and blocks the programs according to your selections. To use this feature, perform the following setup.


### ENABLE BLOCKING

1. From the LOCKS menu, press ▼ or ▲ to highlight ENABLE BLOCKING.
2. Press ◀ or ▶ to select ON (locking enabled) or OFF (locking disabled).

**Note:** The CH LOCK function is not affected by this selection.

### TV RATING (Independent rating system for broadcasters)

1. From the LOCKS menu, press ▼ or ▲ to highlight TV RATING (below left).
2. Press ◀ or ▶ to display the TV RATING menu (below right).



3. Press ▼ or ▲ to select an item.
4. Press ▶ to lock (displays "X"); press ◀ to unlock (displays "✓").
5. Repeat steps 3 and 4 to set the next item.


The TV age-based ratings and content themes you can lock are listed in the following table:

Ratings	Description and content themes
MA	Mature Audience Only (This program is specifically designed to be viewed by adults and therefore may be unsuitable for children under 17.) <b>L) Crude or indecent language S) Explicit sexual activity V) Graphic violence</b>
14	Parents Strongly Cautioned (This program contains some material that many parents would find unsuitable for children under 14 years of age.) <b>D) Intensely suggestive dialog L) Strong, coarse language S) Intense sexual situations V) Intense violence</b>
PG	Parental Guidance Suggested (This program contains material that parents may find unsuitable for younger children.) <b>D) Some suggestive dialog L) Infrequent coarse language S) Some sexual situations V) Moderate violence</b>
G	General Audience (Most parents would find this program suitable for all ages.)
Y7, Y7FV	Directed to Older Children (This program is designed for children age 7 and above. Note: Programs in which fantasy violence may be more intense or more combative than other programs in this category are designated Y7FV.)
Y	All Children (This program is designed to be appropriate for all children)

### Note:


The V-CHIP function is available only for the U.S. V-Chip system. The Canadian V-Chip system (Puce-V) is not supported.

### LOCKS menu




To select each item:

Press ▼ or ▲.




Press RECALL to confirm the rating of the current TV program.



## MPAA RATING (Independent rating system for movies)

1. From the LOCKS menu, select MPAA RATING.
2. Press ◀ or ▶ to display the MPAA RATING menu, and then press ▼ or ▲ to highlight MPAA RATING (below left).
3. Press ◀ or ▶ to display the MPAA RATING menu (below right).




4. Press ▶ to lock ("X") or ◀ to unlock ("✓").

The movie ratings you can lock are described as follows:

- X : X-rated (For adults only)
- NC17: Not intended for anyone 17 and under
- R : Restricted (Under 17 requires accompanying parent or adult guardian)
- PG13 : Parents Strongly Cautioned (Some material may be inappropriate for children under 13)
- PG : Parental Guidance Suggested (Some material may not be suitable for children)
- G : General Audience (Appropriate for all ages)


## BLOCKING OPTION

1. From the LOCKS menu, select BLOCKING OPTION.
2. Press ◀ or ▶ to display the BLOCKING OPTION menu, and then press ▲ or ▼ to select the item.



### MPAA UNRATED:

Press ◀ or ▶ to select ON (locked) or OFF (unlocked) for unrated programs in the MPAA rating system.




### TV NONE RATING:

Press ◀ or ▶ to select ON (Lock) or OFF (Unlock) for programs rated NONE in the TV Parental Guidelines.


**Caution:** Setting the TV NONE RATING to ON may also block emergency messages.

**Note:** The PIP picture is not locked even if TV NONE RATING is set to ON (locked).




### V-CHIP MENU:

Press ◀ or ▶ to return to the LOCKS menu.




## Unlocking programs temporarily

If you try to watch a TV program that exceeds the rating limits you set, the TV will enter the program lock mode.



To temporarily unlock the program:

1. Press MUTE.
2. Press the Channel Number buttons (0–9) to enter your 4-digit PIN code.




3. Press ENTER.

If the code is correct, the lock mode will be released and the normal picture will appear.

All locking is disabled until the TV is turned off, and will be enabled when the TV is turned on again.

If the wrong PIN code is entered, the message “Incorrect” appears. Enter the code again, and then press ENTER.



## Locking channels



Use the CH LOCK feature to lock individual channels. You will not be able to tune locked channels until the setting is cleared.

You can lock a maximum of nine channels.

The current channel cannot be locked.

To lock channels:

1. From the LOCKS menu, select CH LOCK.
2. Press ◀ or ▶ to display the CH LOCK menu. CH INPUT will be highlighted (below left).
3. Press the Channel Number buttons to enter the channel number to be locked, and then press ENTER. The channel number will be added to the list (below right).




4. Repeat step 3 to lock other channels.

(Continued on next page)

To unlock a channel:



1. From the LOCKS menu, select CH LOCK.
2. Press ◀ or ▶ to display the CH LOCK menu. CH INPUT will be highlighted.
3. Press ▲▼◀▶ to highlight the channel to be unlocked.



4. Press ENTER.
5. Repeat steps 3 and 4 for other channels you want to unlock.

To unlock all channels at once:

Press ▲▼◀▶ to highlight CLEAR ALL in step 3 above, and then press ◀ or ▶. All channel numbers will be replaced with "0" in the list.



## Locking the video inputs


You can use the VIDEO LOCK feature to lock out the input sources (Video 1, Video 2, Video 3, ColorStream) and channels 3 and 4. You cannot select the input sources until the setting is cleared.

To set up the video lock:

1. From the LOCKS menu, select VIDEO LOCK.
2. Press ◀ or ▶ to highlight a video lock level, as follows:  
VIDEO: Locks Video 1, Video 2, Video 3, and ColorStream.  
VIDEO+: Locks Video 1, Video 2, Video 3, ColorStream, and channels 3 and 4. Use this option if you connect your VCR through ANT2. **Note:** Make sure the PIP window is not tuned to channel 3 or 4.  
OFF: Unlocks all video input sources.

### Note:

The VIDEO LOCK feature is independent of the ENABLE BLOCKING option.



## Locking the front panel buttons


The front panel buttons can be locked to prevent the TV settings from being changed accidentally (by children, for example). When the front panel lock is ON, all control buttons on the TV front panel (except POWER) do not operate.

To lock the front panel buttons:


1. From the LOCKS menu, select FRONT PANEL LOCK.
2. Press ◀ or ▶ to highlight ON.

To unlock the front panel buttons:

Highlight OFF in step 2 above.



TV front panel




All buttons (except POWER) are locked when the FRONT PANEL LOCK is ON.

**Note:** If a button on the front panel is pressed when the front panel lock feature is ON, the message "Not Available" appears.

## Changing the PIN code

1. From the LOCKS menu, select NEW PIN CODE.
2. Press the Number buttons (0–9) to enter a 4-digit code. The numbers you enter will replace the dashes in the display.
3. Press ENTER. The new PIN code is now active.




## Adjusting the picture

### Selecting the picture mode

You can select your desired picture type from four preset picture modes: sports, standard, movie, and preference.

To select the picture mode:

1. Press MENU, then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▼ or ▲ to select MODE.
3. Press ◀ or ▶ to highlight the mode you prefer.



The table below describes the effects of the different preferences.

Mode	Picture Quality
Sports	Bright and dynamic picture (factory-set)
Standard	Standard picture setting (factory-set)
Movie	Movie-like picture setting (factory-set)
Preference	Your personal preferences*

\*(see “Saving your new picture preferences” on page 40.)


### Adjusting the picture quality

You can adjust the picture quality to your personal preferences, including the contrast, brightness, color, tint, sharpness, flesh tone (page 40), noise reduction (page 40), and color temperature (page 41).


Selection	◀ Pressing ▶	
contrast	lower	higher
brightness	darker	lighter
color	paler	deeper
tint	reddish	greenish
sharpness	softer	sharper

To adjust the picture quality:

1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▼ or ▲ to highlight the quality you want to adjust.
3. Press ◀ or ▶ to adjust the level.



The PICTURE qualities you have adjusted can be saved in the TV's memory with the SAVE NEW PREFERENCE feature (see page 38). You can select your preferences or choose factory-set modes (see “Selecting the picture mode” above).



#### Note:

You must save your new picture quality settings before closing the PICTURE menu, or the TV will return to the previous mode. See “Saving your new picture preferences” on page 40.


If you select SPORTS, STANDARD, or MOVIE picture mode and then change a picture quality setting (for example, increase the contrast), the picture mode automatically changes to PREFERENCE.

## Saving your new picture preferences


You can save the PICTURE qualities you adjusted (contrast, brightness, color, tint, and sharpness) in the picture PREFERENCE mode.

To save your new picture preferences:

1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▲ or ▼ to highlight SAVE NEW PREFERENCE.
3. Press ◀ or ▶. When saved, the menu displays “DONE.”



You can choose your saved preferences by selecting the PREFERENCE mode (see “Selecting the picture mode” on page 39).




## Using the flesh tone feature

This feature makes flesh tones appear more natural by correcting the tint.

To turn on the flesh tone feature:

1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▲ or ▼ to highlight FLESH TONE.
3. Press ◀ or ▶ to highlight ON.



To turn off the flesh tone feature:

Highlight OFF in step 3 above.

## Using the noise reduction feature


This feature allows you to reduce visible interference in your TV picture. This is useful when receiving a broadcast with a weak signal or playing a video tape or disc damaged by repeated use.

To turn on the noise reduction feature:

1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▲ or ▼ to highlight NOISE REDUCTION.
3. Press ◀ or ▶ to highlight ON.

To turn off the noise reduction feature:

Highlight OFF in step 3 above.







## Selecting the color temperature

You can change the quality of the picture by selecting from three preset color temperatures: cool, medium, and warm.

Mode	Picture Quality
cool	blueish
medium	neutral
warm	reddish

To select the color temperature:

1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▲ or ▼ to highlight COLOR TEMPERATURE.
3. Press ◀ or ▶ to highlight the mode you prefer.




## Resetting your picture adjustments

The RESET function returns the picture qualities to the following factory settings:

Contrast ..... max (100)	Color temperature ..... COOL
Brightness ..... center (50)	Noise reduction ..... OFF
Color ..... center (50)	Picture mode ..... SPORTS
Tint ..... center (0)	
Sharpness ..... center (50)	

To reset your picture adjustments:


1. Press MENU, and then press ◀ or ▶ until the PICTURE menu appears.
2. Press ▲ or ▼ to highlight RESET.
3. Press ◀ or ▶. When reset, the menu displays "DONE."




## Watching video input

To view a signal from another device connected to the TV (such as a VCR or DVD player), press INPUT on the remote control (or TV/VIDEO on the TV) to change the video input (see illustrations below).

Select VIDEO 1, VIDEO 2, VIDEO 3, or ColorStream, depending on which input jack is used for connecting the specific device (see “Connecting your TV” on page 7).



Pressing INPUT on the remote control displays this screen. To select, press 0-5.




Pressing TV/VIDEO on the TV displays this screen. To select, press TV/VIDEO.

### Note:

When ColorStream is selected, the video OUT signal will not have color.

To receive a color video OUT signal, a standard video or S-video IN connection must be used instead of the ColorStream connection.




## Selecting the video source labels

This feature allows you to rename the video sources for your TV from the following preset list of labels:


- : Uses the default label name
- VCR : Video cassette recorder
- DVD : DVD video player
- DTV : Digital TV set-top box
- SAT : Satellite box
- CBL : Cable box

To label the video sources:

1. Press MENU, and then press ◀ or ▶ until the CUSTOM menu appears.
2. Press ▲ or ▼ to highlight VIDEO LABEL.




3. Press ◀ or ▶ to display the VIDEO LABEL menu.
4. Press ▲ or ▼ to highlight the video source you want to label.
5. Press ◀ or ▶ to select the appropriate label for that input source.




6. Finish labeling the other video sources as desired. To return to the previous menu, press ▲ or ▼ to highlight CUSTOM MENU, and then press ◀ or ▶.

To exit the menu, press EXIT.

When you press INPUT (or TV/VIDEO), the on-screen display will change according to the labels you assigned (see sample at right).



### Sample video labels




# Using the closed caption feature

The closed caption feature has two options:

- Captions—A printed version of the dialogue, narration and/or sound effects of a program. Close captioned programs are usually designated as “CC” in program guides.
- Text—An on-screen display of information not related to the program, such as weather or stock data (when provided by individual stations).

To view captions or text:

1. Tune the TV to the desired program.
2. Press MENU, and then press ◀ or ▶ until the CUSTOM menu appears.
3. Press ▼ or ▲ to highlight CC.




4. Press ◀ or ▶ to highlight the desired closed caption mode, as follows:
- To view captions, highlight C1, C2, C3, or C4 (C1 displays the primary language in your area).


**Note:** If the program or video you are viewing is not closed captioned, no captions will display on-screen.



- To view text, highlight T1, T2, T3, or T4.
- Note:** If text is not available, a black rectangle may appear on-screen. If this happens, set the closed caption feature to OFF.



- To turn off the closed caption feature, highlight OFF.



**Note:**  
A closed caption signal may not display in the following situations:


- When a video tape has been dubbed
- When the signal reception is weak
- When the signal reception is nonstandard

## Setting the sleep timer

You can use the sleep timer to turn the TV off automatically.

To set the sleep timer:

1. Press SLEEP. Each time you press SLEEP, the time will increase in 10-minute increments, to a maximum of 180.



2. Press ENTER to start the timer.


To cancel the sleep timer:

Press SLEEP until the time is set to 0, or turn off the TV.

## Setting the clock

To set the clock:

1. Press MENU, and then press ◀ or ▶ until the SET UP menu appears.
2. Press ▲ or ▼ to highlight CLOCK SET.
3. After the number position starts to blink, press four Number buttons (0–9) to enter the correct time, and then press ENTER. The clock operates on a 12-hour cycle.



To display the time on-screen:

Press RECALL.


### Note :

The timer can also be set using the MENU and ▲▼◀▶ buttons.

To display the amount of time until the TV turns off automatically, press SLEEP once.

To close the display, press EXIT.

### Note:



If the power source for the TV is interrupted (the power cord is unplugged or a power failure occurs), the clock must be reset.

## Adjusting the sound

### Muting the sound

Press MUTE to temporarily reduce (1/2 mute) or turn off (mute) the sound. The screen will display “1/2 MUTE” or “MUTE” in the lower right corner. Each time MUTE is pressed, the mute mode changes in the following order:

→ 1/2 MUTE → MUTE → Normal

When the TV is muted, the closed caption feature (page 43) is automatically activated (but only if the closed caption mode is set to OFF). To turn off captions, press MUTE again.

### Selecting stereo/SAP broadcasts


The multi-channel TV sound (MTS) feature allows you to listen to high-fidelity stereo sound while watching your TV. MTS can also transmit a second audio program (SAP) containing a second language, music, or other audio information (if available in your area).

When the TV receives a stereo or SAP broadcast, the word STEREO or SAP appears on-screen every time the TV is turned on, the channel is changed, or RECALL is pressed.


**Note:** The MTS feature is not available when the TV is in VIDEO or ColorStream mode.

To listen to stereo sound:

1. Press MENU, and then press ◀ or ▶ until the AUDIO menu appears.



2. Press ▲ or ▼ to highlight MTS.
3. Press ◀ or ▶ to highlight STEREO.




If you leave the TV in STEREO mode, it will automatically output the type of sound being broadcast (stereo or monaural).

If the stereo sound is noisy, select MONO to reduce the noise. The word STEREO or SAP is displayed in yellow in the menu when the TV receives the signal.

To listen to SAP (if available):

1. Press MENU, and then press ◀ or ▶ until the AUDIO menu appears.
2. Press ▲ or ▼ to highlight MTS.
3. Press ◀ or ▶ to highlight SAP. You will hear the station's second audio program (if available) from the speakers, while viewing the program's normal picture (see note at right).



#### **Note:**


A second audio program (SAP) can be heard only on those TV stations that offer it. If you have SAP on, and the station the TV is currently tuned to is in SAP mode but is not currently playing a second audio program, you will see the picture but may not hear sound. If this happens, turn SAP off.

## Using the surround sound feature

The surround sound feature expands the audio listening field wider and deeper to create exceptional sound quality from the TV's speakers. The feature uses stereo signals from a TV broadcast or video input.

To turn on the surround sound feature:


1. Select the STEREO mode (see "Selecting stereo/SAP broadcasts" on page 45).
2. Press MENU, and then press ◀ or ▶ until the THEATER menu appears.
3. Press ▲ or ▼ to highlight SURROUND.
4. Press ◀ or ▶ to highlight MATRIX.



To turn off the surround sound feature:

Highlight OFF in step 4 above.

If you leave the TV in MATRIX mode, it will automatically output the type of sound being broadcast (surround stereo or monaural).



### Note:

When MATRIX surround is selected, the StableSound® feature (page 49) is automatically turned off.




## Adjusting the sound quality

You can change the quality of the TV's sound by adjusting the bass, treble, and balance.

To adjust the sound quality:

1. Press MENU, and then press ◀ or ▶ until the AUDIO menu appears.
2. Press ▲ or ▼ to highlight the item you want to adjust.



3. Press ◀ or ▶ to adjust the level.
  - ◀ makes the sound quality weaker or decreases the balance in the right channel, depending on the item selected.
  - ▶ makes the sound quality stronger or decreases the balance in the left channel, depending on the item selected.



## Resetting your audio adjustments

The RESET function resets your audio adjustments to the following factory settings:

Bass ..... center (50)  
 Treble ..... center (50)  
 Balance ..... center (0)

To reset your audio adjustments:

1. Press MENU, and then press ◀ or ▶ until the AUDIO menu appears.
2. Press ▲ or ▼ to highlight RESET.
3. Press ◀ or ▶. When reset, the menu displays "DONE."




## Using the sub-bass system (SBS)

The sub-bass system allows you to enhance the TV's bass performance (even when the volume is low).


To turn on the SBS:

1. Press MENU, and then press ◀ or ▶ until the AUDIO menu appears.
2. Press ▲ or ▼ to highlight SBS.
3. Press ◀ or ▶ to highlight ON.



To adjust the SBS level:

4. Press ▲ or ▼ to highlight SBS LEVEL.
5. Press ◀ or ▶ to adjust the SBS level.



To turn off the SBS:

Highlight OFF in step 3 above.


## Turning off the built-in speakers

Use this feature to turn the TV speakers off when you connect an audio system (see "Connecting an audio system" on page 11.)

**Note:** Make sure the volume control of your audio amplifier is set to a moderate listening level.

To turn off the built-in speakers:

1. Press MENU, and then press ◀ or ▶ until AUDIO menu appears.
2. Press ▲ or ▼ to highlight SPEAKERS.
3. Press ◀ or ▶ to highlight OFF.




To turn on the built-in speakers:

Highlight ON in step 3 above.

### Note:

The SBS signal does not pass through the "Variable Audio OUT" jacks (see "Connecting an audio system" on page 11); however, the AUDIO menu will appear when the buttons are pressed.




## Selecting the Audio OUT sound

This feature allows you to select the sound (MAIN or PIP) that is output from the Audio OUT jacks.

This is useful when amplifying or recording the PIP sound with external equipment while hearing the sound of the main picture through the built-in speakers.

To select the Audio OUT sound:

1. Press MENU, then press ◀ or ▶ until the AUDIO menu appears.
2. Press ▲ or ▼ to highlight AUDIO OUT.
3. Press ◀ or ▶ to highlight MAIN or PIP.




- MAIN: Main picture sound.
- PIP : Selected PIP sound.

## Using the StableSound® feature

The StableSound® feature limits the highest volume level to prevent extreme changes in volume when the signal source is changed.


To turn on the StableSound feature:

1. Press MENU, and then press ◀ or ▶ until the AUDIO menu appears.
2. Press ▲ or ▼ to highlight STABLE SOUND.
3. Press ◀ or ▶ to select ON.



To turn off the StableSound® feature:

Highlight OFF in step 3 above.



### **Note:**


When the StableSound® feature is turned on, the surround feature is automatically turned off (see page 46).

## Selecting the background of the menu display

You can change the background of the menu display by selecting from two preset types: shaded and solid (gray).

To select the background:


1. Press MENU, and then press ◀ or ▶ until the CUSTOM menu appears.
2. Press ▲ or ▼ to highlight BACKGROUND.
3. Press ◀ or ▶ to highlight either SHADED or SOLID.



## Displaying on-screen information

Press RECALL to display the following information on-screen:

- Antenna mode (when in TV mode)
- Channel number or VIDEO mode selected
- Time (if set)
- Channel label (if set)
- Stereo or SAP (second audio program) audio status
- V-CHIP rating status



## Viewing the demonstration mode



The demonstration mode automatically displays a variety of the TV's on-screen menus and special features. This function is provided for demonstration purposes only.

To start the demonstration mode:

Press DEMO.

To stop the demonstration mode:

Press DEMO, RECALL, EXIT, or POWER.



## Understanding the auto power off feature

The TV will automatically turn off after approximately 15 minutes if it is tuned to a vacant channel or a station that completes its broadcast for the day. This feature does not work in VIDEO mode.

## Understanding the last mode memory feature

If the power is cut off while you are viewing the TV, the Last Mode Memory feature turns the TV on automatically when the power is resupplied.

If the power is going to be off for a long time and you are going to be away from the TV, unplug the power cord to prevent the TV from turning on in your absence.

Introduction

Connecting  
your TV

Using the  
Remote Control

Setting up  
your TV

Using the TV's  
Features

Appendix

# Appendix

## Specifications

Television System	NTSC standard
Channel Coverage	VHF: 2 through 13 UHF: 14 through 69 Cable TV: Mid band (A-8 through A-1, A through I) Super band (J through W) Hyper band (AA through ZZ, AAA, BBB) Ultra band (65 through 94, 100 through 125)
Power Source	120 V AC, 60 Hz
Power Consumption	144 W (average)
Audio Power	14 W + 14 W
Speaker Type	Two 6-1/4 inches (16 cm) round
Video/Audio Terminals	S-VIDEO INPUT Y-INPUT: 1 V(p-p), 75 ohm, negative sync. C-INPUT: 0.286 V(p-p) (burst signal), 75 ohm VIDEO/AUDIO INPUT VIDEO: 1 V(p-p), 75 ohm, negative sync. AUDIO: 150 mV(rms) (30% modulation equivalent, 47 kohm) ColorStream® (component video) INPUT Y : 1V(p-p), 75 ohm Pr (CR): 0.7 V(p-p), 75 ohm Pb (CB): 0.7 V(p-p), 75 ohm AUDIO: 150 mV(rms), 47 kohm VIDEO/AUDIO OUTPUT VIDEO: 1 V(p-p), 75 ohm, negative sync. AUDIO: 150 mV(rms) (30% modulation equivalent, 4.7 kohm) VARIABLE AUDIO OUTPUT 0–300 mV(rms) (30% modulation equivalent, 4.7 kohm) AUDIO CENTER CHANNEL INPUT 300 mV(rms) (30% modulation equivalent, 10 kohm)
Dimensions	Width: 44-7/8 inches (1139 mm) Height: 53-5/16 inches (1354 mm) Depth: 22-3/4 inches (578 mm)
Mass	240 lbs (109 kg)
Supplied Accessories	Remote control with 2 size “AA” alkaline batteries

Design and specifications are subject to change without notice.



## Troubleshooting

Before calling a service technician, please check the following table for a possible cause of the problem and some solutions.

Problem	Solution
TV will not turn on	<ul style="list-style-type: none"><li>• Make sure the power cord is plugged in, and then press POWER.</li><li>• The remote control batteries may be dead. Replace the batteries.</li></ul>
No picture, no sound	<ul style="list-style-type: none"><li>• Check the antenna/cable connections.</li><li>• Press INPUT on the remote control (or TV/VIDEO on the TV) to check the main picture source.</li></ul>
No sound, picture OK	<ul style="list-style-type: none"><li>• The sound may be muted. Press VOLUME.</li><li>• The station may have broadcast difficulties. Try another channel.</li><li>• Make sure the SPEAKERS function in the AUDIO menu is set correctly.</li></ul>
Poor sound, picture OK	<ul style="list-style-type: none"><li>• The station may have broadcast difficulties. Try another channel.</li></ul>
Poor picture, sound OK	<ul style="list-style-type: none"><li>• Check the antenna connections.</li><li>• The station may have broadcast difficulties. Try another channel.</li><li>• Adjust the PICTURE menu.</li></ul>
Poor reception of broadcast channels	<ul style="list-style-type: none"><li>• The station may have broadcast difficulties. Try another channel.</li><li>• Check the antenna connections.</li><li>• If you are using a VCR, make sure the TV/VCR button is set correctly.</li></ul>
Cannot receive above channel 13	<ul style="list-style-type: none"><li>• Make sure the TV/CABLE switch is set to the mode that corresponds with the signal source (cable company or antenna).</li></ul>
A black box appears on-screen	<ul style="list-style-type: none"><li>• The closed caption feature may be set to one of the Text modes (T1, T2, T3, or T4). Set closed captioning to OFF.</li></ul>
Cannot select a certain channel	<ul style="list-style-type: none"><li>• The channel may be locked out with the CH LOCK feature, or erased with the ADD/ERASE feature.</li></ul>
Multiple images	<ul style="list-style-type: none"><li>• The station may have broadcast difficulties. Try another channel.</li><li>• Antenna reception may be poor. Use a highly directional outdoor antenna.</li></ul>
Poor color or no color	<ul style="list-style-type: none"><li>• The station may have broadcast difficulties. Try another channel.</li><li>• Adjust the TINT and/or COLOR in the PICTURE menu.</li><li>• The picture may suffer from color shading (caused by changing the direction of the TV when it is on). Turn off the TV and allow it to cool for 30 minutes.</li></ul>
No stereo or SAP sound from a known MTS broadcast	<ul style="list-style-type: none"><li>• Make sure the MTS feature is set properly.</li></ul>
The remote control does not operate	<ul style="list-style-type: none"><li>• Make sure the appropriate device mode is selected.</li><li>• There may be an obstruction between the remote control and the remote control sensor. Remove the obstruction and retry the remote control.</li><li>• The remote control batteries may be dead. Replace the batteries.</li></ul>
Cannot access signal input sources (VIDEO1, VIDEO2, VIDEO3, ColorStream) and/or channels 3 and 4	<ul style="list-style-type: none"><li>• The VIDEO LOCK feature may be on. Set it to OFF.</li></ul>

# Limited United States Warranty

## for 27" FST PURE® and All Larger Television Models

Toshiba America Consumer Products, Inc. ("TACP") and Toshiba Hawaii, Inc. ("THI") make the following limited warranties to original consumers in the United States. **THESE LIMITED WARRANTIES EXTEND TO THE ORIGINAL CONSUMER PURCHASER OR ANY PERSON RECEIVING THIS TELEVISION AS A GIFT FROM THE ORIGINAL CONSUMER PURCHASER AND TO NO OTHER PURCHASER OR TRANSFEREE.**

**PRODUCTS PURCHASED IN THE U.S.A. AND USED IN CANADA ARE NOT COVERED BY THESE WARRANTIES.**

**PRODUCTS PURCHASED IN CANADA AND USED IN THE U.S.A. ARE NOT COVERED BY THESE WARRANTIES.**

### Limited One (1) Year Warranty on Parts and Labor\*

TACP/THI warrant this television and its parts against defects in materials or workmanship for a period of one (1) year after the date of original retail purchase. **DURING THIS PERIOD, TACP/THI WILL, AT TACP/THI'S OPTION, REPAIR OR REPLACE A DEFECTIVE PART WITH A NEW OR REFURBISHED PART WITHOUT CHARGE TO YOU FOR PARTS OR LABOR.** TACP/THI Authorized Service Station personnel will come to your home when warranty service is required. Depending on the type of repair required, either the service will be performed in your home or the set will be taken to the TACP/THI Authorized Service Station for repair and returned to your home at no cost to you.

### Limited Two (2) Year Warranty on Picture Tube\*

TACP/THI further warrant the picture tube in this television against defects in materials or workmanship for a period of two (2) years after the date of original retail purchase. **DURING THIS PERIOD, TACP/THI WILL, AT TACP/THI'S OPTION, REPAIR OR REPLACE A DEFECTIVE PICTURE TUBE WITH A NEW OR REFURBISHED PICTURE TUBE WITHOUT CHARGE TO YOU, EXCEPT THAT, IF A DEFECTIVE PICTURE TUBE IS REPAIRED OR REPLACED AFTER ONE (1) YEAR FROM THE DATE OF THE ORIGINAL RETAIL PURCHASE, YOU PAY LABOR CHARGES INVOLVED IN THE REPAIR OR REPLACEMENT.**

### Rental Units

The warranty for rental units begins with the date of first rental or thirty (30) days from the date of shipment to the rental firm, whichever comes first.

### \*Commercial Units

Televisions sold and used for commercial purposes have a limited ninety (90) day warranty for all parts, labor, and picture tubes.

### Owner's Manual and Product Registration Card

Read this owner's manual thoroughly before operating this television. Complete and mail the enclosed product registration card within ten days after you, or the person who has given you this product as a gift, purchased this television. Returning the product registration card will enable TACP/THI to provide you with better customer service and improved product support. Failure to return the product registration card will not affect your rights under this warranty.

### Your Responsibility

**THE ABOVE WARRANTIES ARE SUBJECT TO THE FOLLOWING CONDITIONS:**

- (1) You must provide your bill of sale or other proof of purchase.
- (2) All warranty servicing of this television must be made by an Authorized TACP/THI Service Station.
- (3) The warranties from TACP and THI are effective only if the television is purchased and operated in the U.S.A. or Puerto Rico.

- (4) Labor service charges for set installation, setup, adjustment of customer controls, and installation or repair of antenna systems are not covered by these warranties. Reception problems caused by inadequate antenna systems are your responsibility.
- (5) Warranties extend only to defects in materials or workmanship as limited above and do not extend to any television or parts that have been lost or discarded by you or to damage to television or parts caused by misuse, accident, Acts of God (such as lightning or fluctuations in electric power), improper installation, improper maintenance, or use in violation of instructions furnished by TACP/THI; or to units that have been modified or had the serial number removed, altered, defaced, or rendered illegible.

### How to Obtain Warranty Services

If, after following all of the operating instructions in this manual and checking the "Troubleshooting" section, you find that service is needed:

- (1) To find the nearest TACP/THI Authorized Service Station:  
For televisions purchased in the United States, except Hawaii, visit TACP's web site at **[www.toshiba.com/tacp](http://www.toshiba.com/tacp)**, or call toll free 1-800-631-3811.  
For televisions purchased in Hawaii, contact Toshiba Hawaii, Inc., 327 Kamakee Street, Honolulu, HI 96814, (808) 591-9281.
- (2) Present your bill of sale or other proof of purchase to the Authorized Service Station. Authorized TACP/THI Service Station personnel will come to your home when warranty service is required. Depending on the type of repair required, either the service will be performed in your home or the set will be taken to the Authorized Service Station for repair and returned to your home at no cost to you.

**For additional information, visit TACP's web site:  
[www.toshiba.com/tacp](http://www.toshiba.com/tacp).**

**ALL WARRANTIES IMPLIED BY THE LAW OF ANY STATE OF THE U.S.A., INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THE LIMITED WARRANTIES SET FORTH ABOVE. WITH THE EXCEPTION OF ANY WARRANTIES IMPLIED BY THE LAW OF ANY STATE OF THE U.S.A. AS HEREBY LIMITED, THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, GUARANTEES, AGREEMENTS, AND SIMILAR OBLIGATIONS OF TACP OR THI WITH RESPECT TO THE REPAIR OR REPLACEMENT OF ANY PARTS. IN NO EVENT SHALL TACP OR THI BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES.**

No person, agent, distributor, dealer, or company is authorized to change, modify, or extend the terms of these warranties in any manner whatsoever. The time within which action must be commenced to enforce any obligation of TACP or THI arising under this warranty or under any law of the United States or of any state thereof is hereby limited to 90 days from the date you discover, or should have discovered, the defect. This limitation does not apply to implied warranties arising under the law of any state of the U.S.A.

**THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH MAY VARY FROM STATE TO STATE IN THE U.S.A. SOME STATES OF THE U.S.A. DO NOT ALLOW LIMITATIONS ON THE DURATION OF AN IMPLIED WARRANTY, LIMITATIONS ON THE TIME WITHIN WHICH AN ACTION MAY BE BROUGHT, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES; THEREFORE, THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU UNDER SUCH CIRCUMSTANCES.**

FST PURE® is a registered trademark of Toshiba America Consumer Products, Inc.  
REV. MAR02

# Limited Canada Warranty

## for 27" FST PURE® and All Larger Television Models

Toshiba of Canada Limited ("TCL") makes the following limited warranties to original consumers in Canada.

THESE LIMITED WARRANTIES EXTEND TO THE ORIGINAL CONSUMER PURCHASER OR ANY PERSON RECEIVING THIS TELEVISION AS A GIFT FROM THE ORIGINAL CONSUMER PURCHASER AND TO NO OTHER PURCHASER OR TRANSFEREE.

PRODUCTS PURCHASED IN THE U.S.A. AND USED IN CANADA ARE NOT COVERED BY THESE WARRANTIES.

PRODUCTS PURCHASED IN CANADA AND USED IN THE U.S.A. ARE NOT COVERED BY THESE WARRANTIES.

### Limited One (1) Year Warranty on Parts and Labor\*

TCL warrants this television and its parts against defects in materials or workmanship for a period of one (1) year after the date of original retail purchase. DURING THIS PERIOD, TCL WILL, AT TCL'S OPTION, REPAIR OR REPLACE A DEFECTIVE PART WITH A NEW OR REFURBISHED PART WITHOUT CHARGE TO YOU FOR PARTS OR LABOR. TCL Authorized Service Depot personnel will come to your home when warranty service is required. Depending on the type of repair required, either the service will be performed in your home or the set will be taken to the TCL Authorized Service Depot for repair and returned to your home at no cost to you. IN-HOME SERVICE ONLY APPLIES WITHIN 100 KILOMETERS OF AN AUTHORIZED TCL SERVICE DEPOT.

### Limited Two (2) Year Warranty on Picture Tube\*

TCL further warrants the picture tube in this television against defects in materials or workmanship for a period of two (2) years after the date of original retail purchase. DURING THIS PERIOD, TCL WILL, AT TCL'S OPTION, REPAIR OR REPLACE A DEFECTIVE PICTURE TUBE WITH A NEW OR REFURBISHED PICTURE TUBE WITHOUT CHARGE TO YOU, EXCEPT THAT, IF A DEFECTIVE PICTURE TUBE IS REPAIRED OR REPLACED AFTER ONE (1) YEAR FROM THE DATE OF THE ORIGINAL RETAIL PURCHASE, YOU PAY LABOR CHARGES INVOLVED IN THE REPAIR OR REPLACEMENT.

### Rental Units

The warranty for rental units begins with the date of first rental or thirty (30) days from the date of shipment to the rental firm, whichever comes first.

### \*Commercial Units

Televisions sold and used for commercial purposes have a limited ninety (90) day warranty for all parts, labor, and picture tubes.

### Owner's Manual

Read this owner's manual thoroughly before operating this television.

### Your Responsibility

THE ABOVE WARRANTIES ARE SUBJECT TO THE FOLLOWING CONDITIONS:

- (1) You must provide your bill of sale or other proof of purchase.
- (2) All warranty servicing of this television must be made by an Authorized TCL Service Depot.
- (3) The warranties from TCL are effective only if the television is purchased in Canada from an authorized TCL dealer and operated in Canada.

- (4) Labor service charges for set installation, setup, adjustment of customer controls, and installation or repair of antenna systems are not covered by these warranties. Reception problems caused by inadequate antenna systems are your responsibility.
- (5) Warranties extend only to defects in materials or workmanship as limited above and do not extend to any television or parts that have been lost or discarded by you or to damage to television or parts caused by misuse, accident, Acts of God (such as lightning or fluctuations in electric power), improper installation, improper maintenance, or use in violation of instructions furnished by TCL; or to units that have been modified or had the serial number removed, altered, defaced, or rendered illegible.

### How to Obtain Warranty Services

If, after following all of the operating instructions in this manual and checking the "Troubleshooting" section, you find that service is needed:

- (1) To find the nearest TCL Authorized Service Depot, visit TCL's web site: **www.toshiba.ca**.
- (2) Present your bill of sale or other proof of purchase to the Authorized Service Depot. Authorized TCL Service Depot personnel will come to your home when warranty service is required. Depending on the type of repair required, either the service will be performed in your home or the set will be taken to the Authorized Service Depot for repair and returned to your home at no cost to you. IN-HOME SERVICE ONLY APPLIES WITHIN 100 KILOMETERS OF AN AUTHORIZED TCL SERVICE DEPOT.

**For additional information, visit TCL's web site:  
www.toshiba.ca**

ALL WARRANTIES IMPLIED BY THE LAW OF ANY PROVINCE OF CANADA, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THE LIMITED WARRANTIES SET FORTH ABOVE. WITH THE EXCEPTION OF ANY WARRANTIES IMPLIED BY THE LAW OF ANY PROVINCE OF CANADA AS HEREBY LIMITED, THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, GUARANTEES, AGREEMENTS, AND SIMILAR OBLIGATIONS OF TCL WITH RESPECT TO THE REPAIR OR REPLACEMENT OF ANY PARTS. IN NO EVENT SHALL TCL BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES.

No person, agent, distributor, dealer, or company is authorized to change, modify, or extend the terms of these warranties in any manner whatsoever. The time within which action must be commenced to enforce any obligation of TCL arising under this warranty or under any law of Canada or of any province thereof, is hereby limited to 90 days from the date you discover, or should have discovered, the defect. This limitation does not apply to implied warranties arising under the law of any province of Canada.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH MAY VARY FROM PROVINCE TO PROVINCE IN CANADA. SOME PROVINCES OF CANADA DO NOT ALLOW LIMITATIONS ON THE DURATION OF AN IMPLIED WARRANTY, LIMITATIONS ON THE TIME WITHIN WHICH AN ACTION MAY BE BROUGHT, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES; THEREFORE, THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU UNDER SUCH CIRCUMSTANCES.

FST PURE® is a registered trademark of Toshiba America Consumer Products, Inc.  
REV. MAR02

Introduction

Connecting  
your TV

Using the  
Remote Control

Setting up  
your TV

Using the TV's  
Features

Appendix

# **TOSHIBA AMERICA CONSUMER PRODUCTS, INC.**

HEAD OFFICE/82 TOTOWA ROAD, WAYNE, NEW JERSEY 07470  
NATIONAL SERVICE DIVISION/1420B TOSHIBA DRIVE, LEBANON, TN 37087

# **TOSHIBA HAWAII, INC.**

HEAD OFFICE/327 KAMAKEE STREET, HONOLULU, HAWAII 96814, U.S.A. TEL: (808) 591-9281

# **TOSHIBA OF CANADA LTD.**

HEAD OFFICE/191 McNABB STREET MARKHAM, ONTARIO L3R 8H2, CANADA TEL: (905) 470-5400  
SERVICE CENTERS/TORONTO: 191 McNABB STREET MARKHAM, ONTARIO L3R 8H2, CANADA TEL: (905) 470-5400  
MONTREAL: 1643, NORTH SERVICE RD., TRANS-CANADA HIGHWAY, DORVAL QUEBEC, H9P 1J1, CANADA  
TEL: (514) 856-4100  
VANCOUVER: 22171 FRASERWOOD WAY, RICHMOND, B.C. V6W 1J5, CANADA TEL: (604) 303-2500

MANUFACTURED BY

**TOSHIBA AMERICA CONSUMER PRODUCTS, INC.**

ColorStream and StableSound are registered trademarks of Toshiba America Consumer Products, Inc.

PRINTED IN USA  
(02-08) B

# **TOSHIBA**